

# NESPRESSO GEMINI 220 USER GUIDE

Watch videos on how to use the Nespresso Gemini 220 coffee pod machine on our website [www.podmachinehire.com.au/videos](http://www.podmachinehire.com.au/videos)



## STEP 1

Ensure both water tanks (number 5) are at least half filled with water. Power the machine on by pressing the Power button (number 1). The machine will take a few minutes to warm up and prepare to make coffees. Please follow any prompts on the screen.



## STEP 2 (for milk based coffees)

Fill up the milk container (number 10) with your preferred milk. Attach the straw and nozzle kit to the container and attach to the milk froth outlet (number 3).

## STEP 3

Select your desired Nespresso coffee pod, insert the pod into the capsule insertion slot (number 12) on either the left or right side of the machine. Ensure you have a coffee cup directly under the coffee outlet (number 7). Press either the Ristretto, Espresso or Lungo button (number 6). The coffee will be extracted into your coffee cup.




### Ristretto



### Espresso



### Lungo



## STEP 4

For non-milk coffees - top up your coffee with hot water by pressing the hot water button (number 4). Ensure your coffee cup is under the hot water nozzle.



For milk based coffees - place your coffee cup under the milk frother nozzle. Press the top milk button (number 2) once to start the automatic flow of milk and then press once again to stop. Press the button milk button (number 2) to manually add the milk to your coffee.

*If the milk frother does not release milk consistently, ensure the milk container is full of milk, press and hold the manual milk button or replace the straw and nozzle with a new one.*

## ENJOY YOUR COFFEE!

